



Remote control

RTAC1 19POL

099-008197-EW501

Observe additional system documents!

12.08.2013

**Register now!**  
For your benefit  
**Jetzt Registrieren**  
und Profitieren!

[www.ewm-group.com](http://www.ewm-group.com)



## General instructions

### CAUTION



#### **Read the operating instructions!**

**The operating instructions provide an introduction to the safe use of the products.**

- Read the operating instructions for all system components!
- Observe accident prevention regulations!
- Observe all local regulations!
- Confirm with a signature where appropriate.

### NOTE



**In the event of queries on installation, commissioning, operation or special conditions at the installation site, or on usage, please contact your sales partner or our customer service department on +49 2680 181-0.**

**A list of authorised sales partners can be found at [www.ewm-group.com](http://www.ewm-group.com).**

Liability relating to the operation of this equipment is restricted solely to the function of the equipment. No other form of liability, regardless of type, shall be accepted. This exclusion of liability shall be deemed accepted by the user on commissioning the equipment.

The manufacturer is unable to monitor whether or not these instructions or the conditions and methods are observed during installation, operation, usage and maintenance of the equipment.

An incorrectly performed installation can result in material damage and injure persons as a result. For this reason, we do not accept any responsibility or liability for losses, damages or costs arising from incorrect installation, improper operation or incorrect usage and maintenance or any actions connected to this in any way.

# 1 Contents

|          |  |           |
|----------|--|-----------|
| <b>1</b> | <b>Contents</b> .....                                      | <b>3</b>  |
| <b>2</b> | <b>Safety instructions</b> .....                           | <b>4</b>  |
| 2.1      | Notes on the use of these operating instructions .....     | 4         |
| 2.2      | Explanation of icons.....                                  | 5         |
| 2.3      | General .....  | 6         |
| 2.4      | Transport.....   | 8         |
| 2.5      | Scope of delivery .....                                    | 8         |
| 2.5.1    | Ambient conditions .....                                   | 8         |
| 2.5.1.1  | In operation .....   | 8         |
| 2.5.1.2  | Transport and storage.....                                 | 8         |
| <b>3</b> | <b>Intended use</b> .....                                  | <b>9</b>  |
| 3.1      | Use and operation solely with the following machines ..... | 9         |
| 3.2      | Documents which also apply .....                           | 9         |
| 3.2.1    | Warranty .....   | 9         |
| 3.2.2    | Declaration of Conformity.....                             | 9         |
| 3.2.3    | Service documents (spare parts) .....                      | 9         |
| <b>4</b> | <b>Machine description – quick overview</b> .....          | <b>10</b> |
| 4.1      | Front view .....   | 10        |
| <b>5</b> | <b>Design and function</b> .....                           | <b>11</b> |
| 5.1      | General .....  | 11        |
| 5.2      | Connecting the remote control.....                         | 11        |
| 5.3      | Basic settings.....  | 11        |
| 5.4      | Standard Mode .....  | 11        |
| <b>6</b> | <b>Maintenance, care and disposal</b> .....                | <b>12</b> |
| 6.1      | General .....  | 12        |
| 6.2      | Maintenance work.....                                      | 12        |
| 6.3      | Maintenance work, intervals .....                          | 12        |
| 6.3.1    | Monthly maintenance tasks.....                             | 12        |
| 6.4      | Disposing of equipment .....                               | 12        |
| 6.4.1    | Manufacturer's declaration to the end user .....           | 13        |
| 6.5      | Meeting the requirements of RoHS .....                     | 13        |
| <b>7</b> | <b>Technical data</b> .....                                | <b>14</b> |
| 7.1      | RTAC1 19POL.....   | 14        |
| <b>8</b> | <b>Accessories</b> .....                                   | <b>15</b> |
| 8.1      | Connection and extension cables.....                       | 15        |
| <b>9</b> | <b>Appendix A</b> .....                                    | <b>16</b> |
| 9.1      | Overview of EWM branches .....                             | 16        |

## 2 Safety instructions

### 2.1 Notes on the use of these operating instructions



#### **DANGER**

**Working or operating procedures which must be closely observed to prevent imminent serious and even fatal injuries.**

- Safety notes include the "DANGER" keyword in the heading with a general warning symbol.
- The hazard is also highlighted using a symbol on the edge of the page.



#### **WARNING**

**Working or operating procedures which must be closely observed to prevent serious and even fatal injuries.**

- Safety notes include the "WARNING" keyword in the heading with a general warning symbol.
- The hazard is also highlighted using a symbol in the page margin.



#### **CAUTION**

**Working or operating procedures which must be closely observed to prevent possible minor personal injury.**

- The safety information includes the "CAUTION" keyword in its heading with a general warning symbol.
- The risk is explained using a symbol on the edge of the page.

#### **CAUTION**

**Working and operating procedures which must be followed precisely to avoid damaging or destroying the product.**

- The safety information includes the "CAUTION" keyword in its heading without a general warning symbol.
- The hazard is explained using a symbol at the edge of the page.

#### **NOTE**














**Special technical points which users must observe.**

- Notes include the "NOTE" keyword in the heading without a general warning symbol.

Instructions and lists detailing step-by-step actions for given situations can be recognised via bullet points, e.g.:

- Insert the welding current lead socket into the relevant socket and lock.

## 2.2 Explanation of icons

| Symbol  | Description   |
|---|---|
|    | Press   |
|    | Do not press  |
|    | Turn  |
|    | Switch  |
|    | Switch off machine  |
|    | Switch on machine   |
|    | ENTER (enter the menu)  |
|    | NAVIGATION (Navigating in the menu)                               |
|   | EXIT (Exit the menu)  |
|  | Time display (example: wait 4s/press)                             |
|  | Interruption in the menu display (other setting options possible) |
|  | Tool not required/do not use                                      |
|  | Tool required/use   |

## 2.3 General

### DANGER



#### Electric shock!

**Welding machines use high voltages which can result in potentially fatal electric shocks and burns on contact. Even low voltages can cause you to get a shock and lead to accidents.**

- Do not touch any live parts in or on the machine!
- Connection cables and leads must be free of faults!
- Switching off alone is not sufficient!
- Place welding torch and stick electrode holder on an insulated surface!
- The unit should only be opened by specialist staff after the mains plug has been unplugged!
- Only wear dry protective clothing!
- Wait for 4 minutes until the capacitors have discharged!



#### Electromagnetic fields!

**The power source may cause electrical or electromagnetic fields to be produced which could affect the correct functioning of electronic equipment such as IT or CNC devices, telecommunication lines, power cables, signal lines and pacemakers.**

- Observe the maintenance instructions! (see Maintenance and Testing chapter)
- Unwind welding leads completely!
- Shield devices or equipment sensitive to radiation accordingly!
- The correct functioning of pacemakers may be affected (obtain advice from a doctor if necessary).



#### Validity of this document!

**This document describes an accessory and is only valid in combination with the operating instructions for the power source being used (welding machine)!**

- Read the operating instructions, in particular the safety instructions for the power source (welding machine)!

### WARNING



#### Risk of accidents if these safety instructions are not observed!

**Non-observance of these safety instructions is potentially fatal!**

- Carefully read the safety information in this manual!
- Observe the accident prevention regulations in your country.
- Inform persons in the working area that they must observe the regulations!



#### Fire hazard!

**Flames may arise as a result of the high temperatures, stray sparks, glowing-hot parts and hot slag produced during the welding process.**

**Stray welding currents can also result in flames forming!**

- Check for fire hazards in the working area!
- Do not carry any easily flammable objects such as matches or lighters.
- Keep appropriate fire extinguishing equipment to hand in the working area!
- Thoroughly remove any residue of flammable substances from the workpiece before starting welding.
- Only continue work on welded workpieces once they have cooled down.  
Do not allow to come into contact with flammable material!
- Connect welding leads correctly!

 **WARNING****Risk of injury due to radiation or heat!****Arc radiation results in injury to skin and eyes.****Contact with hot workpieces and sparks results in burns.**

- Use welding shield or welding helmet with the appropriate safety level (depending on the application)!
- Wear dry protective clothing (e.g. welding shield, gloves, etc.) according to the relevant regulations in the country in question!
- Protect persons not involved in the work against arc beams and the risk of glare using safety curtains!

**Hazards due to improper usage!****Hazards may arise for persons, animals and material objects if the equipment is not used correctly. No liability is accepted for any damages arising from improper usage!**

- The equipment must only be used in line with proper usage and by trained or expert staff!
- Do not modify or convert the equipment improperly!

 **CAUTION****Noise exposure!****Noise exceeding 70 dBA can cause permanent hearing damage!**

- Wear suitable ear protection!
- Persons located within the working area must wear suitable ear protection!

**CAUTION****Obligations of the operator!****The respective national directives and laws must be observed for operation of the machine!**

- National implementation of the framework directive (89/391/EEG), as well as the associated individual directives.
- In particular, directive (89/655/EEG), on the minimum regulations for safety and health protection when staff members use equipment during work.
- The regulations regarding work safety and accident prevention for the respective country.
- Setting up and operating the machine according to IEC 60974-9.
- Check at regular intervals that users are working in a safety-conscious way.
- Regular checks of the machine according to IEC 60974-4.

**Damage due to the use of non-genuine parts!****The manufacturer's warranty becomes void if non-genuine parts are used!**

- Only use system components and options (power sources, welding torches, electrode holders, remote controls, spare parts and replacement parts, etc.) from our range of products!
- Only insert and lock accessory components into the relevant connection socket when the machine is switched off.

**Trained personnel!****Commissioning is reserved for persons who have the relevant expertise of working with arc welding machines.**

## 2.4 Transport

### CAUTION



**Damage due to supply lines not being disconnected!**

**During transport, supply lines which have not been disconnected (mains supply leads, control leads, etc.) may cause hazards such as connected equipment tipping over and injuring persons!**

- Disconnect supply lines!

## 2.5 Scope of delivery

The delivery is checked and packaged carefully before dispatch, however it is not possible to exclude the possibility of damage during transit.

### Receiving inspection

- Check that the delivery is complete using the delivery note!

### In the event of damage to the packaging

- Check the delivery for damage (visual inspection)!

### In the event of complaints

If the delivery has been damaged during transport:

- Please contact the last haulier immediately!
- Keep the packaging (for possible checking by the haulier or for the return shipment).

### Packaging for returns

If possible, please use the original packaging and the original packaging material. If you have any queries on packaging and protection during transport, please contact your supplier.

### 2.5.1 Ambient conditions

#### CAUTION



**Equipment damage due to dirt accumulation!**

**Unusually high quantities of dust, acid, corrosive gases or substances may damage the equipment.**

- Avoid high volumes of smoke, vapour, oil vapour and grinding dust!
- Avoid ambient air containing salt (sea air)!

#### 2.5.1.1 In operation

**Temperature range of the ambient air:**

- -25 °C to +40 °C

**Relative air humidity:**

- Up to 50% at 40 °C
- Up to 90% at 20 °C

#### 2.5.1.2 Transport and storage

**Storage in an enclosed space, temperature range of the ambient air:**

- -30 °C to +70 °C

**Relative air humidity**

- Up to 90% at 20 °C



### 3 Intended use

#### WARNING



##### **Hazards due to improper usage!**

**Hazards may arise for persons, animals and material objects if the equipment is not used correctly. No liability is accepted for any damages arising from improper usage!**

- The equipment must only be used in line with proper usage and by trained or expert staff!
- Do not modify or convert the equipment improperly!

#### 3.1 Use and operation solely with the following machines

- Tetrax 301, 351, 421, 451, 521, 551 AC/DC
- Tetrax 300 AC/DC
- Tetrax 270, 350, 500 AC/DC
- Tetrax 352 AC/DC Synergic
- Tetrax 350 AC/DC Plasma

#### 3.2 Documents which also apply

##### 3.2.1 Warranty

#### NOTE



For further information, please see the accompanying supplementary sheets "Machine and Company Data, Maintenance and Testing, Warranty"!

##### 3.2.2 Declaration of Conformity



The designated machine conforms to EC Directives and standards in terms of its design and construction:

- EC Low Voltage Directive (2006/95/EC),
- EC EMC Directive (2004/108/EC),

This declaration shall become null and void in the event of unauthorised modifications, improperly conducted repairs, non-observance of the deadlines for the repetition test and / or non-permitted conversion work not specifically authorised by the manufacturer.

The original copy of the declaration of conformity is enclosed with the unit.

##### 3.2.3 Service documents (spare parts)

#### DANGER



**Do not carry out any unauthorised repairs or modifications!**

**To avoid injury and equipment damage, the unit must only be repaired or modified by specialist, skilled persons!**

**The warranty becomes null and void in the event of unauthorised interference.**

- Appoint only skilled persons for repair work (trained service personnel)!

Spare parts can be obtained from the relevant authorised dealer.

## 4 Machine description – quick overview

### 4.1 Front view




Figure 4-1

| Item | Symbol | Description   |
|------|--------|---|
| 1    |        | <p><b>Alternating current balance (TIG AC)</b><br/>                     Max. setting range: -15% to +15% (1% increments). The setting range may also be lower depending on the factory setting.<br/>                     Optimisation of cleaning effect and fusion penetration characteristics.</p> <p><b>An increase in the positive half-wave means:</b></p> <ul style="list-style-type: none"> <li>• greater cleaning effect</li> <li>• higher temperature of the tungsten electrode</li> <li>• greater ball formation on the tungsten electrode</li> <li>• broader weld seam, little fusion penetration</li> </ul> <p><b>An increase in the negative half-wave means:</b></p> <ul style="list-style-type: none"> <li>• narrower weld seam, deeper fusion penetration</li> <li>• reduced cleaning effect</li> <li>• lower temperature of the tungsten electrode</li> <li>• less ball formation on the tungsten electrode</li> </ul> |
| 2    |        | <p><b>Alternating current frequency (TIG AC)</b><br/>                     50 Hz to 200 Hz (1 Hz increments).<br/>                     Constriction and stabilisation of the arc:<br/>                     At a higher frequency, the cleaning effect is increased. Particularly thin panels (welding with a low current), anodised sheet aluminium or highly contaminated articles for welding can be welded and cleaned perfectly at a higher frequency.</p>   |
| 3    |        | <p><b>Welding current rotary dial</b><br/>                     Infinitely adjustable welding current, 0% to 100% of the main current preset on the power source.</p>  |
| 4    |        | <p><b>19-pole connection socket (analogue)</b><br/>                     For connecting the control lead.</p>  |
| 5    |        | <p><b>Remote control connector cable</b><br/>                     Use a 5, 10, or 20 m connector cable, depending on the design, for connecting the remote control to the power source.</p>   |

## 5 Design and function

### 5.1 General

#### NOTE

Basically, all descriptions on the process settings in the standard operating instructions shall apply. This operating manual exclusively describes deviating control functions.

### 5.2 Connecting the remote control

#### CAUTION



**Damage to the machine due to improper connection!**

The remote controls have been developed to be connected to welding machines or wire feed units only. Connecting them to other machines may cause damage to the machines!

- Observe the operating instructions for the welding machine or wire feed unit!
- Switch off the welding machine before connecting!

#### NOTE

Observe documentation of other system components when connecting!

- Switch off the welding machine
- Insert the male connector plug (socket) into the remote control connection socket and lock by turning to the right.
- Insert the male connector plug (pin) into the remote control connection socket of the welding machine and lock by turning to the right.

### 5.3 Basic settings

- Preset the maximum welding current required for the welding task on the welding machine, set the welding parameters for the welding task correspondingly, and ensure that the unit is set to TIG welding.

### 5.4 Standard Mode

| Operating element | Action | Result                              |
|-------------------|--------|-------------------------------------|
|                   |        | Set a reduced welding current       |
|                   |        | Set alternating current frequency   |
|                   |        | Set the alternating current balance |

## 6 Maintenance, care and disposal

### 6.1 General

When used in the specified environmental conditions and under normal operating conditions, this machine is largely maintenance-free and requires a minimum of care.

There are some points, which should be observed, to guarantee fault-free operation of your welding machine. Among these are regular cleaning and checking as described below, depending on the pollution level of the environment and the length of time the unit is in use.

### 6.2 Maintenance work

#### DANGER



**Do not carry out any unauthorised repairs or modifications!**

**To avoid injury and equipment damage, the unit must only be repaired or modified by specialist, skilled persons!**

**The warranty becomes null and void in the event of unauthorised interference.**

- Appoint only skilled persons for repair work (trained service personnel)!

Repair and maintenance work may only be performed by qualified authorised personnel; otherwise the right to claim under warranty is void. In all service matters, always consult the dealer who supplied the machine. Return deliveries of defective equipment subject to warranty may only be made through your dealer. When replacing parts, use only original spare parts. When ordering spare parts, please quote the machine type, serial number and item number of the machine, as well as the type designation and item number of the spare part.

### 6.3 Maintenance work, intervals

#### 6.3.1 Monthly maintenance tasks

- Check control leads and their strain relief for damage.
- Carry out functional test of operating, signalling, safety and/or adjustment devices.
- Other, general condition

### 6.4 Disposing of equipment

#### NOTE



**Proper disposal!**

**The machine contains valuable raw materials, which should be recycled, and electronic components, which must be disposed of.**

- Do not dispose of in household waste!
- Observe the local regulations regarding disposal!



## 6.4.1 Manufacturer's declaration to the end user

- According to European provisions (guideline 2002/96/EG of the European Parliament and the Council of January, 27th 2003), used electric and electronic equipment may no longer be placed in unsorted municipal waste. It must be collected separately. The symbol depicting a waste container on wheels indicates that the equipment must be collected separately.  
This machine is to be placed for disposal or recycling in the waste separation systems provided for this purpose.
- According to German law (law governing the distribution, taking back and environmentally correct disposal of electric and electronic equipment (ElektroG) from 16.03.2005), used machines are to be placed in a collection system separate from unsorted municipal waste. The public waste management utilities (communities) have created collection points at which used equipment from private households can be disposed of free of charge.
- Information about giving back used equipment or about collections can be obtained from the respective municipal administration office.
- EWM participates in an approved waste disposal and recycling system and is registered in the Used Electrical Equipment Register (EAR) under number WEEE DE 57686922.
- In addition to this, returns are also possible throughout Europe via EWM sales partners.

## 6.5 Meeting the requirements of RoHS

We, EWM HIGHTEC Welding GmbH Mündersbach, hereby confirm that all products supplied by us which are affected by the RoHS Directive, meet the requirements of the RoHS (Directive 2002/95/EC).

## 7 Technical data

### NOTE



Performance specifications and guarantee only in connection with original spare and replacement parts!

### 7.1 RTAC1 19POL

|                  |                   |
|------------------|-------------------|
| Interface        | 19-pole           |
| Dimensions L/W/H | 260 x 150 x 75 mm |
| Weight           | 1,5 kg            |

**8 Accessories****8.1 Connection and extension cables**

| Type           | Designation                          | Item no.         |
|----------------|--------------------------------------|------------------|
| RA5 19POL 5M   | Remote control e.g. connection cable | 092-001470-00005 |
| RA10 19POL 10M | Remote control e.g. connection cable | 092-001470-00010 |
| RA20 19POL 20M | Remote control e.g. connection cable | 092-001470-00020 |

## 9 Appendix A

### 9.1 Overview of EWM branches

#### Headquarters

**EWM HIGHTEC WELDING GmbH**  
 Dr. Günter-Henle-Straße 8  
 56271 Mündersbach · Germany  
 Tel: +49 2680 181-0 · Fax: -244  
 www.ewm-group.com · info@ewm-group.com

#### Technology centre

**EWM HIGHTEC WELDING GmbH**  
 Forststraße 7-13  
 56271 Mündersbach · Germany  
 Tel: +49 2680 181-0 · Fax: -144  
 www.ewm-group.com · info@ewm-group.com



#### Production, Sales and Service

EWM HIGHTEC WELDING GmbH  
 Dr. Günter-Henle-Straße 8  
 56271 Mündersbach · Germany  
 Tel: +49 2680 181-0 · Fax: -244  
 www.ewm-group.com · info@ewm-group.com

EWM HIGHTEC WELDING AUTOMATION GmbH  
 Boxbachweg 4  
 08606 Oelsnitz/V. · Germany  
 Tel: +49 37421 20-300 · Fax: -318  
 www.ewm-automation.de · info@ewm-automation.de

EWM HIGHTEC WELDING (Kunshan) Ltd.  
 10 Yuanshan Road, Kunshan · New & High-tech Industry Development Zone  
 Kunshan · Jiangsu · 215300 · People's Republic of China  
 Tel: +86 512 57867-188 · Fax: -182  
 www.ewm-kunshan.cn · info@ewm-kunshan.cn

EWM HIGHTEC WELDING s.r.o.  
 Tr. 9. května 718 / 31  
 407 53 Jirřkov · Czech Republic  
 Tel: +420 412 358-551 · Fax: -504  
 www.ewm-jirřkov.cz · info@ewm-jirřkov.cz

#### Sales and Service Germany

EWM HIGHTEC WELDING GmbH  
 Vertriebs- und Technologiezentrum  
 Grünaauer Fenn 4  
 14712 Rathenow · Tel: +49 3385 49402-0 · Fax: -20  
 www.ewm-rathenow.de · info@ewm-rathenow.de

EWM HIGHTEC WELDING GmbH  
 Vertriebs- und Technologiezentrum  
 Dralsstraße 2a  
 69469 Weinheim · Tel: +49 6201 84557-0 · Fax: -20  
 www.ewm-weinheim.de · info@ewm-weinheim.de

EWM HIGHTEC WELDING GmbH  
 Lindenstraße 1a  
 38723 Seesen-Rhüden · Tel: +49 5384 90798-0 · Fax: -20  
 www.ewm-seesen.de · info@ewm-seesen.de

EWM Schweißtechnik Handels GmbH  
 Bildstock 9/3-4  
 88085 Langenargen · Tel: +49 7543 9344-30 · Fax: -50  
 www.ewm-langenargen.de · info@ewm-langenargen.de

EWM HIGHTEC WELDING GmbH  
 Sachsstraße 28  
 50259 Pulheim · Tel: +49 2234 697-047 · Fax: -048  
 www.ewm-pulheim.de · info@ewm-pulheim.de

EWM Schweißtechnik Handels GmbH  
 Rittergasse 1  
 89143 Blaubeuren · Tel: +49 7344 9191-75 · Fax: -77  
 www.ewm-blaubeuren.de · info@ewm-blaubeuren.de

EWM HIGHTEC WELDING GmbH  
 Vertriebs- und Logistikzentrum  
 Sälzerstraße 20  
 56235 Ransbach-Baumbach · Tel: +49 2623 9276-0 · Fax: -244  
 www.ewm-ransbach-baumbach.de · info@ewm-ransbach-baumbach.de

EWM Schweißtechnik Handels GmbH  
 Heinkelstraße 8  
 89231 Neu-Ulm · Tel: +49 731 7047939-0 · Fax: -15  
 www.ewm-neu-ulm.de · info@ewm-neu-ulm.de

EWM HIGHTEC WELDING GmbH  
 Eiserfelder Straße 300  
 57080 Siegen · Tel: +49 271 3878103-0 · Fax: -9  
 www.ewm-siegen.de · info@ewm-siegen.de

EWM HIGHTEC WELDING AUTOMATION GmbH  
 Steinfeldstrasse 15  
 90425 Nürnberg · Tel: +49 911 3841-727 · Fax: -728  
 www.ewm-automation.de · info@ewm-automation.de

#### Sales and Service International

EWM HIGHTEC WELDING GmbH  
 Fichtenweg 1  
 4810 Gmunden · Austria · Tel: +43 7612 778 02-0 · Fax: -20  
 www.ewm-gmunden.at · info@ewm-gmunden.at

EWM HIGHTEC WELDING UK Ltd.  
 Unit 2B Coopies Way · Coopies Lane Industrial Estate  
 Morpeth · Northumberland · NE61 6JN · Great Britain  
 Tel: +44 1670 505875 · Fax: -514305  
 www.ewm-morpeth.co.uk · info@ewm-morpeth.co.uk

EWM HIGHTEC WELDING (Kunshan) Ltd.  
 10 Yuanshan Road, Kunshan · New & High-tech Industry Development Zone  
 Kunshan · Jiangsu · 215300 · People's Republic of China  
 Tel: +86 512 57867-188 · Fax: -182  
 www.ewm-kunshan.cn · info@ewm-kunshan.cn

EWM HIGHTEC WELDING Sales s.r.o. / Prodejní a poradenské centrum  
 Tyrřova 2106  
 256 01 Beneřov u Prahy · Czech Republic  
 Tel: +420 317 729-517 · Fax: -712  
 www.ewm-benesov.cz · info@ewm-benesov.cz